

PRODUCT	MODEL NUMBER	RoHS MODEL NUMBER
QS2500 - 5 years warranty		
QuickScan 2500 Linear Imager Handheld Scanner		
RS232, GR, single interface, no stand, cable or power supply	QS25-1100	QS25-1100R
RS232, BLK, single interface, no stand, cable or power supply	QS25-1300-00	QS25-1300-00R
KBW/Wand Emulation, GR,dual interface, no stand, cable or power supply	QS25-2100	QS25-2100R
KBW/Wand Emulation, BLK, dual interface, no stand, cable or power supply	QS25-2300-00	QS25-2300-00R
USB (Series A), GR, single interface, no stand, cable or power supply	QS25-3100	QS25-3100R
USB (Series A), BLK, single interface, no stand, cable or power supply	QS25-3200-00	QS25-3200-00R
IBM 46XX POS, GR, single interface, no stand, cable or power supply	QS25-4100	QS25-4100R
IBM USB (Power Plus), GR, single interface, no stand, cable or power supply	QS25-5100	QS25-5100R
IBM USB (Power Plus), BLK, single interface, no stand, cable or power supply	QS25-5200-00	QS25-5200-00R
QuickScan 2500 Interface Cables		
KBW, 5/6DIN, IBM AT/PS2, POT, 11 ft	8-0424-03	8-0738-03
KBW, Laptop, 12 ft	8-0424-06	8-0738-06
RS232, DB9S, 8 feet	8-0423-03	8-0736-03
RS232, DB9S, POT, 12 ft	8-0423-17	8-0736-17
RS232, External Power, 25DSUB, 12 ft	8-0423-02	8-0736-02
RS232, External Power, 25DSUB, 8 ft	8-0423-01	8-0736-01
RS232, DB9S, External Power, 12 ft	8-0423-80	8-0736-80
USB, Series A, POT, 12 ft	8-0481-08	8-0734-08
WE, 9D Sub, 8 ft	8-0422-02	8-0740-02
WE, RJ-6, 8 ft	8-0422-03	8-0740-03
IBM 46XX, POT, Port 5B, 12 ft	8-0429-02	8-0739-02
IBM 46XX, POT, Port 9B, 12 ft	8-0429-04	8-0739-04
IBM USB, POT, 12 ft	8-0481-12	8-0481-12
RS232, Aux Port on Magellan 8X00/9500	8-0577-11	8-0737-11
RS232, Aux Port on Magellan 2X00	8-0577-10	8-0737-10
QuickScan 2500 Accessories		
Gooseneck Tabletop Stand, Gray	7-0803	11-0179
Gooseneck Tabletop Stand, Black	7-0832	11-0190
Power Supply, AC/DC, 230V, Europe	4004-0746	4004-0801
Power Supply, AC/DC, 230V, UK	4004-0753	4004-0818
Product Reference Guide (Printed, not included with product)	R44-2398	R44-2398
Quick Reference Guide	R44-2399	R44-2399
QS6500 - 5 years warranty		
QS6500 Scanner Only Multi-Interface - RS232 Default (no Cable, Stand, or CD Included)		
1D only Decoding with Multi-Interface, Gray (Default I/F is KBW)	QS65-1030000	QS65-1030000R
1D plus PDF, Micro-PDF Decoding with Multi-Interface, Gray (Default I/F is KBW)	QS65-2030000	QS65-2030000R
1D only Decoding with Multi-Interface, Black (Default I/F is KBW)	QS65-3030000	QS65-3030000R
1D plus PDF, Micro-PDF Decoding with Multi-Interface, Black (Default I/F is KBW)	QS65-4030000	QS65-4030000R
<i>Add cable and power supply as separate line items, or order bundled product.</i>		
QuickScan 6500 Interface Cables		
RS232, External Power, 25DSUB, 8 feet	8-0423-01	8-0736-01
RS232, External Power, 25DSUB, 12 feet	8-0423-02	8-0736-02
RS232, DB9S, 8 feet	8-0423-03	8-0736-03
RS232, DB9S, 12 feet	8-0423-17	8-0736-17
RS232, 9D, S, External Power, 12 Feet	8-0423-80	8-0736-80
RS232, 10RJ, P, Mal 22/23 Aux Port, POT, 12 feet	8-0577-10	8-0737-10
RS232, 10RJ, P, Mgl 82/85/95 Aux Port, POT, 12 feet	8-0577-11	8-0737-11
RS232, 80IN, P, SATO, POT, 8 feet	8-0577-12	8-0737-12
KBW, 5/6DIN, IBM AT/PS2, POT, 8+3 feet	8-0671-01	8-0741-03
IBM 4683, Port 5B, 12 feet	8-0429-02	8-0739-02
IBM 4683, Port 9B, 12 feet	8-0429-04	8-0739-04
IBM USB POT, 12 feet	8-0481-12	8-0481-12
IBM USB (Power Plus) POT, 15 feet	8-0481-15	8-0734-15
USB, POT, 6ft	8-0481-10	8-0734-10
USB, Series A, High Speed, POT,12 feet	8-0481-16	8-0734-16
WE, 9 Dsub, Cable Select, 8'	8-0422-02	8-0740-02
WE, RJ6 Connector, Coil, 8'	8-0422-03	8-0740-03
<i>For additional cables, contact your Customer Account Specialist or go to the CABLE SELECTOR at www.pscnet.com</i>		
QuickScan 6500 Accessories		
AC/DC Power Supply, 230 volt, Europe	4004-0709	4004-0798
AC/DC Power Supply, 230 volt, UK	4004-0706	4004-0795
Hands Free Stand, Gray	8-0681-01	8-0755-01
Hands Free Stand, Black	8-0681-02	8-0755-02
Holder, Gray	7-0393	7-0393
Holder, Black	7-0840	7-0840
Product Manuals CD (contains PDF files of all available manuals), included with scanner	8-0682-01	8-0682-01
Product Reference Guide (Printed, not included with product)	R44-2467	R44-2467
Quick Reference Guide (included with all shipments)	R44-2466	R44-2466
QS6500 BLUETOOTH - 3 years warranty		
QS6500BT EZ Kits w/ Base Station (Multi-Interface is set to RS232)		
1D plus PDF, Micro-PDF Decoding with Multi-Interface Base Station, Gray (Default I/F is RS232)	QS65B-1010000	QS65B-1010000R
1D plus PDF, Micro-PDF Decoding with Multi-Interface Base Station, Black (Default I/F is RS232)	QS65B-3010000	QS65B-3010000R
QuickScan® QS6500BT Accessories		
AC/DC Power Supply, 230 volt, Europe	4004-0709	4004-0798
AC/DC Power Supply, 230 volt, UK	4004-0706	4004-0795
Accessory, Wall Mount, QS6500BT	11-0129	11-0129
Accessory, Table Mount, QS6500BT	11-0130	11-0130
Product Manuals CD (contains PDF files of all available manuals), included with scanner	8-0682-01	8-0682-01
Product Reference Guide (Printed, not included with product)	R44-2467	R44-2467
Quick Reference Guide (included with all shipments)	R44-2545	R44-2545
QuickScan® QS6500BT Cables		
RS232, External Power, 25DSUB, 8 feet	8-0423-01	8-0736-01
RS232, External Power, 25DSUB, 12 feet	8-0423-02	8-0736-02
RS232, DB9S, 8 feet	8-0423-03	8-0736-03
RS232, SNI, W/DTR, Blk, 12 feet	8-0423-04	8-0736-04
RS232, DB9S, 12 feet	8-0423-17	8-0736-17
RS232, 9D, S, External Power, 12 Feet	8-0423-80	8-0736-80
RS232, 10RJ, P, Mal 22/23 Aux Port, 12 feet	8-0577-10	8-0737-10
RS232, 10RJ, P, Mal 82/85/95 Aux Port, 12 feet	8-0577-11	8-0737-11
RS232, ADP, IBM, ENTRY 01 TURK, RJ8	8-0103-16	8-0770-16
RS232, 80IN, P, SATO, 8 feet	8-0577-12	8-0737-12
KBW, 5/6DIN, IBM AT/PS2, 8+3 feet	8-0671-01	8-0741-03
KBW, 6MDIN,P,12 feet	8-0671-02	TBD
KBW, 25D,S,E/P,12 feet	8-0671-03	8-0741-16
IBM 4683, Port 5B, 12 feet	8-0429-02	8-0739-02
IBM 4683, Port 9B, 12 feet	8-0429-04	8-0739-04
IBM USB POT, 12 feet	8-0481-12	8-0481-12
IBM USB POT, 15 feet	8-0481-15	8-0734-15
USB, 12 feet coiled	8-0481-16	8-0734-16
WE, 9D SUB, Cbl SEL, 8 feet	8-0422-02	8-0740-02
WE, RJ6, Coil, 8 feet	8-0422-03	8-0740-03
<i>For Power Off Terminal applications it is recommended that you use IBM USB interface cables.</i>		

PRODUCT	MODEL NUMBER	RoHS MODEL NUMBER
POWERSCAN 7000 - 4 years warranty		
PowerScan 7000 Scanner Only, No Pointer PowerScan 7000 RS232, Ylw/Blk, SR, No Pointer PowerScan 7000 KBW, Ylw/Blk, SR, No Pointer PowerScan 7000 USB HID KB, Ylw/Blk, SR, No Pointer PowerScan 7000 Wand Emulation, Ylw/Blk, SR, No Pointer	PS70-1010000 PS70-1020000 PS70-1030000 PS70-1060000	P570-1010000R P570-1020000R P570-1030000R P570-1060000R
PowerScan 7000 Scanner Only, Pointer PowerScan 7000 RS232, Ylw/Blk, SR w/ Pointer PowerScan 7000 KBW, Ylw/Blk, SR w/ Pointer PowerScan 7000 USB HID KB, Ylw/Blk, SR w/ Pointer PowerScan 7000 Wand Emulation, Ylw/Blk, SR w/ Pointer	PS70-1110001 PS70-1120001 PS70-1130001 PS70-1160001	P570-1110001R P570-1120001R P570-1130001R P570-1160001R
PowerScan 7000 Accessories Power Supply, AC/DC 230V, Europe PowerHood Padded Cover Hands-free Stand Universal Mounting Kit for PowerScan Industrial Take-up Reel Heated Holder, 24 Volt Heated Holder, 36 Volt Heated Holder, 48 Volt Manual, Product Reference Guide	4004-0709 11-0109 11-0110 11-0111 7-0404 7-0658 7-0659 7-0660 R44-2530	4004-0798 11-0109 11-0110 11-0111 7-0404 11-0139 11-0138 11-0140 R44-2530
PowerScan 7000 Cables RS232 Cable, Ext. Pwr., 25 Dsub, Coil, 8' RS232 Cable, Ext. Pwr., 25 Dsub, 2' RS232 Cable, DB9S, Coil, 8' RS232 Cable, DB9S, Ext. Pwr., 2' KBW, 5 DIN, PC, Ext. Pwr., 2' KBW, 6MDIN, POT/Ext. Pwr., 2' USB Series A Cable, POT, 2' USB Series A Cable, POT, High Speed, 2M	8-0423-01 8-0423-02 8-0423-03 8-0423-80 8-0671-01 8-0671-03 8-0481-08 8-0481-10	8-0736-01 8-0736-02 8-0736-03 8-0736-80 8-0741-03 8-0741-16 8-0734-08 8-0734-10
POWERSCAN 7000 2D IMAGER - 5 years warranty		
PowerScan 7000 2D Imager Scanner Only PowerScan 7000 2D RS232, Ylw/Blk, SR PowerScan 7000 2D RS232, Ylw/Blk, HD PowerScan 7000 2D USB, Ylw/Blk, SR PowerScan 7000 2D USB, Ylw/Blk, HD PowerScan 7000 2D KBW, Ylw/Blk, SR PowerScan 7000 2D KBW, Ylw/Blk, HD	PS72-1000-0100 PS72-1100-0100 PS72-2000-0200 PS72-2100-0200 PS72-3000-0300 PS72-3100-0300	P572-1000-0100 P572-1100-0100 P572-2000-0200 P572-2100-0200 P572-3000-0300 P572-3100-0300
PowerScan® 7000 2D Imager Accessories Power Supply, AC/DC 230V, Europe PowerHood Padded Cover Hands-free Stand (PowerScan 7000 2D) Universal Mounting Kit for PowerScan 7000 Industrial Take-up Reel Heated Holder, 24V Heated Holder, 36V Heated Holder, 48V	4004-0798 11-0109 11-0113 11-0111 7-0404 7-0658 7-0659 7-0660	4004-0798 11-0109 11-0113 11-0111 7-0404 11-0139 11-0138 11-0140
PowerScan 7000 2D Imager Cables RS232 Cable, Ext. Pwr., 25 Dsub, Coil, 8' RS232 Cable, Ext. Pwr., 25 Dsub, 12' RS232 Cable, DB9S, Coil, 8' RS232 Cable, DB9S, Ext. Pwr., 12' KBW, 5 DIN, PC, Ext. Pwr., 12 feet KBW, 6MDIN, POT/Ext. Pwr., 12 feet USB Series A Cable, POT, 12' USB Series A Cable, POT, High Speed, 2M	8-0736-01 8-0736-02 8-0736-03 8-0736-80 8-0741-03 8-0741-16 8-0734-08 8-0734-10	8-0736-01 8-0736-02 8-0736-03 8-0736-80 8-0741-03 8-0741-16 8-0734-08 8-0734-10
POWERSCAN - 3 years warranty		
PowerScan Standard Range (SR) RS232/Standard Keyboard Wedge/Wand-Emulation Interface Undecoded Interface USB/Universal Keyboard Wedge Interface	PSSR-1000 PSSR-0000 PSSR-7000	P5SR-1000R P5SR-0000R P5SR-7000R
PowerScan High Density (HD) RS232/Standard Keyboard Wedge/Wand-Emulation Interface USB/Universal Keyboard Wedge Interface	PSHD-1000 PSHD-7000	P5HD-1000R P5HD-7000R
PowerScan Long Range (LR) RS232/Standard Keyboard Wedge/Wand-Emulation Interface Undecoded Interface USB/Universal Keyboard Wedge Interface	PSLR-1000 PSLR-0000 PSLR-7000	P5LR-1000R P5LR-0000R P5LR-7000R
PowerScan Extra Long Range (XLR) RS232/Standard Keyboard Wedge/Wand-Emulation Interface Undecoded Interface USB/Universal Keyboard Wedge Interface	PSXLR-1000 PSXLR-0000 PSXLR-7000	P5XLR-1000R P5XLR-0000R P5XLR-7000R
PowerScan / PowerScan Imager Accessories Power Supply, AC/DC 230V, Europe Universal mounting kit Holster/Fork Lift Mount kit Industrial Take-up Reel PowerHood Padded Cover AutoSense stand Heated Holder, 24 Volt Heated Holder, 36 Volt Heated Holder, 48 Volt Product Reference Guide, Imager Programming Guide Programming Guide, Universal Wedge User's Guide, English User's Guide, European	4004-0709 7-0462 7-0519 7-0404 11-0060 11-0095 7-0658 7-0659 7-0660 R44-2464 R44-2172 R44-2021 R44-2094 R44-2095	4004-0798 11-0191 7-0519 7-0404 11-0060 11-0133 11-0139 11-0138 11-0140 R44-2464 R44-2172 R44-2021 R44-2094 R44-2095
PowerScan RF Scanner Only, Standard Range (SR) 433MHz - with Battery RS232/Standard Keyboard Wedge/Wand-Emulation Interface Universal Keyboard Wedge/USB Interface	PSRF-1010 PSRF-8010	PSRF-1010R PSRF-8010R
PowerScan RF Scanner Only, High Density (HD) 433MHz - with Battery Universal Keyboard Wedge/USB Interface	PSRF-8110	PSRF-8110R
PowerScan RF Scanner Only, Long Range (LR) 433MHz - with Battery RS232/Standard Keyboard Wedge/Wand-Emulation Interface Universal Keyboard Wedge/USB Interface	PSRF-1210 PSRF-8210	PSRF-1210R PSRF-8210R
PowerScan RF Scanner Only, Extra Long Range (XLR) 433MHz - with Battery RS232/Standard Keyboard Wedge/Wand-Emulation Interface Universal Keyboard Wedge/USB Interface	PSRF-1310 PSRF-8310	PSRF-1310R PSRF-8310R
PowerScan RF Base Station, 433MHz (without Power Supply and Cable) RS232/Standard Keyboard Wedge/Wand-Emulation Interface USB/Universal Keyboard Wedge Interface	PSB-1010 PSB-7010	PSB-1010R PSB-7010R
PowerScan RF Accessories Power Supply, AC/DC, 120V, Wall Mount, US Quick Change battery pack (each) Four-Station battery pack charger (includes power supply), Europe Kit, Conversion, Forklift, 18 to 36 Volt Kit, Conversion, Forklift, 48 to 72 Volt RF Systems Manual RF Users Guide (included with scanner) Integrated RF Programming Manual	4004-0705 10-2427 7-0565 7-0625 7-0626 R44-2114 R44-2100 R44-2168	4004-0794 10-2427 11-0181 11-0185 11-0186 R44-2114 R44-2100 R44-2168
PowerScan Interface Cables RS232, External Power, 25DSUB, 8 feet RS232, External Power, 25DSUB, 12 feet RS232, DB9S, POT, 8 feet RS232, DB9S, External Power, 12 feet RS232, DB9S, POT, 12 feet WE, 6 pin, RJ SQZ, Coiled, 8 feet WE, 9DSUB, SEL, 8 feet WE, RJ6 Connector, 8 feet WE, LSE, Lemo-7M, POT, 8 feet KBW, 5/6DIN, IBM AT/PS2, POT, 11 feet KBW, Laptop, 12 feet KBW, 6MDIN, P, POT, 11 feet Undecoded, 8 feet Undecoded, 9 pin Dsub, Coil, 12 feet Undecoded, DE9S, SQZ, SOS High, Coil, 8 feet Undecoded, 9 pin D, Coil, 20 feet Undecoded, 8 pin mod jack, 12 feet Undecoded, 9 pin Dsub, Coil, 10 feet USB, Series A, POT, 12 ft. USB, Series A, POT, 6.5 ft. (2m) UKBW, 25pin, External Power, 12 feet	8-0423-01 8-0423-02 8-0423-03 8-0423-80 8-0423-17 8-0422-01 8-0422-02 8-0422-03 8-0422-09 8-0424-03 8-0424-06 8-0424-17 8-0419-01 8-0419-02 8-0419-03 8-0419-05 8-0419-06 8-0419-13 8-0481-08 8-0481-10 8-0424-16	8-0736-01 8-0736-02 8-0736-03 8-0736-80 8-0736-17 8-0740-01 8-0740-02 8-0740-03 8-0740-09 8-0738-03 8-0738-06 8-0738-17 8-0742-01 8-0742-02 8-0742-03 8-0742-05 8-0742-06 8-0742-13 8-0742-16 8-0734-08 8-0734-10 8-0738-16



PRODUCT	MODEL NUMBER	RoHS MODEL NUMBER
MAGELLAN 1000i		
PLEASE NOTE: Magellan 1000i Prices Effective July 1, 2006		
Magellan 1000i Scanner Only - 5V Magellan 1000i Black 5V No Button, RS232, Scanner Only Magellan 1000i Grey 5V No Button, RS232, Scanner Only Magellan 1000i Black 5V w/Targeting Mode, RS232, Scanner Only Magellan 1000i Grey 5V w/Targeting Mode, RS232, Scanner Only	MG10-0010-000 MG10-1010-000 MG10-2010-000 MG10-3010-000	MG100010-000R MG101010-000R MG102010-000R MG103010-000R
Magellan 1000i Scanner Only - 12V Magellan 1000i Black 12V No Button, RS232, Scanner Only Magellan 1000i Grey 12V No Button, RS232, Scanner Only Magellan 1000i Black 12V w/Targeting Mode, RS232, Scanner Only Magellan 1000i Grey 12V w/Targeting Mode, RS232, Scanner Only	MG10-4010-000 MG10-5010-000 MG10-6010-000 MG10-7010-000	MG104010-000R MG105010-000R MG106010-000R MG107010-000R
<i>5V version is recommended for USB/KBW/WE connection or RS232 connection with external power supply 12V version is recommended for POT connection up to 5V (i.e. IBM Port 9B, IBM USB Powered, WINIX Beetle)</i>		
Magellan® 1000i Accessories P/S, AC/DC, 120V, US - for 5V Version P/S, AC/DC, 230V, Europe - for 5V Version P/S, AC/DC, 230V, UK - for 5V Version Power Supply, AC/DC 230V, Europe - for 12V Version Black 3" Riser Stand w/ Tilt Adjustment and Fixed Mounting Holes Grey 3" Riser Stand w/ Tilt Adjustment and Fixed Mounting Holes Black Fixed Mounting Plate Grey Fixed Mounting Plate	4004-0745 4004-0746 4004-0753 4004-0709 11-0114 11-0115 11-0116 11-0117	4004-0826 4004-0801 4004-0818 4004-0798 11-0114 11-0115 11-0116 11-0117
Magellan® 1000i Cables RS232, External Power, 25DSUB, 8 feet RS232, External Power, 25DSUB, 12 feet RS232, DB9S, 8 feet RS232, SNI, W/DTR, Blk, 12 feet RS232, DB9S, 12', Straight RS232, DB9S, 12', Coiled RS232, 9D, S, External Power, 12', Straight RS232, 9D, S, External Power, 12', Coiled RS232, 10RJ, P, Mgl 22/23 Aux Port, POT, 12 feet RS232, 10RJ, P, Mgl 82/85/95 Aux Port, POT, 12 feet RS232, 8DIN, P, SATO, POT, 8 feet KBW, 60DIN, IBM AT/PS2, E/P, 8+3, Straight KBW, 5/6DIN, IBM AT/PS2, POT, 8+3 feet KBW, 6MDIN, IBM POT/External Power, 12 feet IBM 4683, Port 5B, 12', Coiled IBM 4683, Port 9B, 12', Coiled IBM 4683, Port 5B, 12', Straight IBM 4683, Port 9B, 12', Straight IBM USB POT, 12 feet IBM USB POT, 15 feet IBM USB POT w/ EAS, 12', Straight IBM USB, POT, 12', Straight USB, POT, 12' Coiled	8-0423-01 8-0423-02 8-0423-03 8-0423-04 8-0751-02 8-0423-17 8-0751-03 8-0423-80 8-0577-10 8-0577-11 8-0577-12 8-0752-01 8-0671-01 8-0671-02 8-0429-02 8-0429-04 8-0753-02 8-0753-01 8-0481-12 8-0481-12 8-0754-01 8-0754-01 8-0754-02 8-0481-16	8-0736-01 8-0736-02 8-0736-03 8-0736-04 8-0751-02 8-0736-17 8-0751-03 8-0736-80 8-0737-10 8-0737-11 8-0737-12 8-0752-01 8-0741-03 TBD 8-0739-02 8-0739-04 8-0753-02 8-0753-01 8-0481-12 8-0481-12 8-0734-15 8-0754-01 8-0754-02 8-0734-16
MAGELLAN 2200VS OmegaTek		
Magellan 2200VS Ω Vertical Scanner Mgl 2200 VS Ω, Multi-Interface, RSS, FirstStrike S/W, Std Counter Mount, No Cable or Power Supply	M22-01	M22-01R
Magellan 2200VS Ω Optional Software Features Productivity Index Reporting EAS Checkpoint Antenna	Software PIR 10-3320	Software PIR 10-3320
Magellan 2200VS Ω Cables IBM USB, E/P, 4.5m (15 ft.) IBM USB, POT, 4.5m (15ft.) USB, Type A, E/P, 4.5m (15 ft.) IBM, Port 17 (16 pin), 4.5m (15 ft.) IBM, Port 17 (16 pin), POT, 4.5m (15 ft.) IBM, Port 9B (4 pin), 4.5m (15 ft.) IBM, Port 9B (4 pin), POT, 4.5m (15 ft.) RS232, 9D for SNI Beetle, POT, 4.5m (15ft.) RS232, PC D-Sub/25 Pin, 4.5m (15 ft.) RS232, PC D-Sub/9 Pin, 4.5m (15 ft.) KBW, 5/6 Din, IBM AT/PS2, PCXT, External Power, 4.5m (15 ft.) Aux Port Cable for PSC RS232 Handhelds, 4.5m (15ft.) Aux Port Cable for PSC RS232 Handhelds, 4.5m (15ft.) w/ EAS Interlock	8-0525-01 8-0525-03 8-0525-04 8-0224-01 8-0224-09 8-0224-02 8-0224-08 8-0227-30 8-0227-33 8-0227-04 8-0641-01 8-0577-10 8-0577-17	8-0732-01 8-0732-03 8-0732-04 8-0731-01 8-0731-09 8-0731-02 8-0731-08 8-0730-30 8-0730-33 8-0730-04 8-0641-01 8-0737-10 8-0737-17
Magellan 2200VS Ω Accessories Europe 220V Power Supply Product Manuals CD (included with scanner) Product Reference Guide (Printed, not included with product) Quick Reference Guide (Included with product) Riser Mount (Elevates scanner off of counter surface 5cm / 2") Standard Counter Mounting Bracket (included with scanner at N/C) Europe Desktop Power Supply, (requires power cord 6003-0921) Power Cord, AC, IEC/EUR	4004-0709 8-0610-01 R44-2365 R44-2364 11-0022 11-0006 4004-0727 6003-0921	4004-0798 8-0610-01 R44-2365 R44-2364 11-0174 11-0006 4004-0800 6003-0921
MAGELLAN 2300HS OmegaTek		
Magellan 2300HS Ω Horizontal Scanner Mgl 2300HS Ω, Multi-Interface, FirstStrike, QRG, RSS, Tin Oxide Top, No Cable or Power Supply Mgl 2300HS Ω, Multi-Interface, FirstStrike, QRG, RSS, DLC Top, No Cable or Power Supply Mgl 2300HS Ω, Multi-Interface, FirstStrike, QRG, RSS, Sapphire Top, No Cable or Power Supply	M23-031 M23-021 M23-011	M23-031R M23-021R M23-011R
Magellan 2300HS Ω Options Productivity Index Reporting EAS Checkpoint Antenna	Software PIR 10-3320	Software PIR 10-3320
Magellan 2300HS Ω Interface Cables RS232, PC D-Sub/9 Pin, 4.5m (15 ft.) RS232, PC D-Sub/25 Pin, 4.5m (15 ft.) RS232, 9D for SNI Beetle, 4.5m (15ft.) IBM, Port 17 (16 pin), 4.5m (15 ft.) IBM, Port 9B (4 pin), 4.5m (15 ft.) IBM, Port 17 (16 pin), POT, 4.5m (15 ft.) IBM, Port 9B (4 pin), POT, 4.5m (15 ft.) KBW, 5/6 Din, IBM AT/PS2, PCXT, External Power, 4.5m (15 ft.) IBM USB, E/P, 4.5m (15 ft.) IBM USB, POT, 4.5m (15ft.) USB, Type A, E/P, 4.5m (15 ft.) Aux Port Cable for PSC RS232 Handhelds, 4.5m (15ft.) Aux Port Cable for PSC RS232 Handhelds, 4.5m (15ft.) w/ EAS Interlock <i>For additional cables, contact your Customer Account Specialist or go to the CABLE SELECTOR at www.oscnet.com</i>	8-0227-04 8-0227-33 8-0227-30 8-0224-01 8-0224-02 8-0224-09 8-0224-08 8-0641-01 8-0525-01 8-0525-03 8-0525-04 8-0577-10 8-0577-17	8-0730-04 8-0730-33 8-0730-30 8-0731-01 8-0731-02 8-0731-09 8-0731-08 8-0735-01 8-0732-01 8-0732-03 8-0732-04 8-0737-10 8-0737-17
Magellan 2300HS Ω Accessories Power Supply, 230V, Europe Europe Desktop Power Supply, (requires power cord 6003-0921) Power Cord, AC, IEC/EUR Standard Counter Mount HS1250 Counter Mount Symbol 5800 Counter Mount Quick Reference Guide (Included w/ all scanners, hardcopy sold separately) Product Reference Guide (Included on Product CD, hardcopy sold separately)	4004-0709 4004-0727 6003-0921 11-0027 11-0028 FK-5800 R44-2367 R44-2365	4004-0798 4004-0800 6003-0921 11-0027 11-0178 FK-5800 R44-2367 R44-2365
IntelliCompass Software IntelliCompass, 1-100 Lanes IntelliCompass, 101-500 Lanes IntelliCompass, >500 Lanes	11-0061 11-0062 11-0063	11-0061R 11-0062R 11-0063R

PRODUCT	MODEL NUMBER	RoHS MODEL NUMBER
MAGELLAN 8100 OmegaTek		
Magellan 8100Q Scanner Only, Std RS232, Long Platter - Model 8103 Mgl 8100Q TO Glass, RSS and FirstStrike software. No cable or power supply. Mgl 8100Q DLC Glass with HS1250 Fill Kit, RSS and FirstStrike software. No Cable or Power Supply Mgl 8100Q LLT Glass, RSS and FirstStrike software. No cable or power supply.	MG811-1141 MG811-1091 MG811-1011	MG811-1141R MG811-1091R MG811-1011R
Magellan 8100Q Scanner Only, Std RS232, Medium Platter - Model 8101 Mgl 8100Q TO Glass, RSS and FirstStrike software. No Cable or Power Supply Mgl 8100Q DLC Glass, RSS and FirstStrike software. No Cable or Power Supply Mgl 8100Q LLT Glass, RSS and FirstStrike software. No cable or power supply.	MG811-1161 MG811-1111 MG811-1041	MG811-1161R MG811-1111R MG811-1041R
Magellan 8100Q Scanner Only, Std RS232, Short Platter - Model 8100 Mgl 8100Q TO Glass, RSS and FirstStrike software. No Cable or Power Supply Mgl 8100Q DLC Glass, RSS and FirstStrike software. No Cable or Power Supply Mgl 8100Q LLT Glass, RSS and FirstStrike software. No cable or power supply.	MG811-1181 MG811-1131 MG811-1081	MG811-1181R MG811-1131R MG811-1081R
Magellan 8100Q Platter Options All-Weights Produce Lift Bar for Scanner Only Units	See Matrix	See Matrix
Magellan 8100Q Interface Cables IBM USB Plus Power Kit (includes power adapter and 15' interface cable) IBM USB, external power, 4.5m (15 ft.) IBM, Port 17 (16 pin), 4.5m (15 ft.) IBM, Port 9B (4 pin), 4.5m (15 ft.) RS232, PC D-Sub/25 Pin, 4.5m (15 ft.) RS232, PC D-Sub/9 Pin, 4.5m (15 ft.) RS232, 4 Pin RJ Connector for SASI, 4.5m (15 ft.) RS232, Scale cable for PC D-Sub/ 9 Pin, 4.5m (15 ft.) RS232, Scale cable for SASI, 8 Pin RJ connector, 4.5m (15 ft.) EAS Interconnect Cable, Sensormatic to Magellan 8100/8200 and 8500	7-0752 8-0525-01 8-0224-01 8-0224-02 8-0224-02 8-0227-33 8-0227-04 8-0227-05 8-0229-05 8-0229-04 8-0769-01	11-0172 8-0732-01 8-0731-01 8-0731-02 8-0730-33 8-0730-04 8-0730-05 8-0733-05 8-0733-04 8-0733-04
Magellan 8100Q Accessories DLC Replacement Glass EAS Antenna Cable EAS Interlock Cable (Requires EAS antenna cable) Power Cord, 110V, US Standard (requires power supply) Power Cord, 220V, Europe Power Cord, 220V, Italy/Chile Power Cord, 240V, UK Product Manuals CD (included with scanner) Product Reference Guide (Printed, not included with product) Quick Reference Guide (included with product) Tin Oxide Replacement Glass Universal Power Supply (requires power cord) US Power Supply Kit (includes supply and standard power cord)	7-0735 8-0268 8-0278 10-0695 10-0694 10-0696 10-0699 10-0697 8-0607-01 R44-2382 R44-2381 7-0757 7-0685 7-0751	7-0735 8-0769-02 8-0769-03 6003-0922 8-0481 6003-0921 6003-0924 6003-0923 8-0607-01 R44-2382 R44-2381 7-0757 11-0164 11-0171
MAGELLAN 8200 OmegaTek		
Magellan 8200Q Scanner Only, Long Platter - Model 8203 Mgl 8200 Multi-interface, DLC Glass, RSS and FirstStrike software. No cable or power supply. Mgl 8200 Multi-interface, Sapphire Glass, RSS and FirstStrike software. No cable or power supply.	MG821-1011 MG821-1021	MG821-1011R MG821-1021R
Magellan 8200Q Scanner Only, Medium Platter - Model 8201 Mgl 8200Q Multi-interface, DLC Glass, RSS and FirstStrike software. No Cable or Power Supply Mgl 8200Q Multi-interface, Sapphire Glass, RSS and FirstStrike software. No Cable or Power Supply	MG821-1031 MG821-1041	MG821-1031R MG821-1041R
Magellan 8200Q Scanner Only, Short Platter - Model 8200 Mgl 8200Q Multi-interface, DLC Glass, RSS and FirstStrike software. No Cable or Power Supply Mgl 8200Q Multi-interface, Sapphire Glass, RSS and FirstStrike software. No Cable or Power Supply	MG821-1051 MG821-1061	MG821-1051R MG821-1061R
Magellan 8200Q Platter Options All-Weights Produce Lift Bar for Scanner Only Units	See Matrix	See Matrix
Magellan 8200Q Optional Software Features Productivity Index Reporting	See Matrix	See Matrix
Magellan 8200Q Interface Cables IBM USB Plus Power Kit (includes power adapter and 15' interface cable) IBM USB, external power, 4.5m (15 ft.) IBM, Port 17 (16 pin), 4.5m (15 ft.) IBM, Port 9B (4 pin), 4.5m (15 ft.) RS232, PC D-Sub/25 Pin, 4.5m (15 ft.) RS232, PC D-Sub/9 Pin, 4.5m (15 ft.) RS232, 4 Pin RJ Connector for SASI, 4.5m (15 ft.) RS232, Scale cable for PC D-Sub/ 9 Pin, 4.5m (15 ft.) RS232, Scale cable for SASI, 8 Pin RJ connector, 4.5m (15 ft.) EAS Interconnect Cable, Sensormatic to Magellan 8100/8200 and 8500	7-0752 8-0525-01 8-0224-01 8-0224-02 8-0227-33 8-0227-04 8-0227-05 8-0229-05 8-0229-04 8-0769-01	11-0172 8-0732-01 8-0731-01 8-0731-02 8-0730-33 8-0730-04 8-0730-05 8-0733-05 8-0733-04 8-0769-01
Magellan 8200Q Accessories DLC Replacement Glass EAS Antenna Cable EAS Interlock Cable (Requires EAS antenna cable) Power Cord, 110V, US Standard (requires power supply) Power Cord, 110V, US Twist and Lock (requires power supply) Power Cord, 220V, Europe Power Cord, 220V, Italy/Chile Power Cord, 240V, UK Product Manuals CD (included with scanner) Product Reference Guide (Printed, not included with product) Quick Reference Guide (included with product) Universal Power Supply (requires power cord) US Power Supply Kit (includes supply and standard power cord)	7-0735 8-0268 8-0278 10-0695 10-0694 10-0696 10-0699 10-0697 8-0607-01 R44-2382 R44-2381 7-0685 7-0751	7-0735 8-0769-02 8-0769-03 6003-0922 8-0481 6003-0921 6003-0924 6003-0923 8-0607-01 R44-2382 R44-2381 11-0164 11-0171
MAGELLAN 8500 OmegaTek		
Magellan 8500Q Scanner Only, Long Platter - Model 8501 Mgl 8500Q Multi-interface, DLC Glass, RSS and FirstStrike software. No cable or power supply Mgl 8500Q Multi-interface, Sapphire Glass, RSS and FirstStrike software. No cable or power supply	MG851-111 MG851-121	MG851-111R MG851-121R
Magellan 8500Q Scanner Only, Short Platter - Model 8500 Mgl 8500Q Multi-interface, DLC Glass, RSS and FirstStrike software. No cable or power supply Mgl 8500Q Multi-interface, Sapphire Glass, RSS and FirstStrike software. No cable or power supply	MG851-131 MG851-141	MG851-131R MG851-141R
Magellan 8500Q Optional Software Features Productivity Index Reporting Cashier Training EAS Checkpoint Antenna	See Matrix See Matrix See Matrix	See Matrix See Matrix See Matrix
Magellan 8500Q Interface Cables IBM USB Plus Power Kit (includes power adapter and 15' interface cable) IBM USB, external power, 4.5m (15 ft.) IBM, Port 17 (16 pin), 4.5m (15 ft.) IBM, Port 9B (4 pin), 4.5m (15 ft.) RS232, PC D-Sub/25 Pin, 4.5m (15 ft.) RS232, PC D-Sub/9 Pin, 4.5m (15 ft.) RS232, 4 Pin RJ Connector for SASI, 4.5m (15 ft.) RS232, Scale cable for PC D-Sub/ 9 Pin, 4.5m (15 ft.) RS232, Scale cable for SASI, 8 Pin RJ connector, 4.5m (15 ft.) EAS Interconnect Cable, Sensormatic to Magellan 8100/8200 and 8500	7-0752 8-0525-01 8-0224-01 8-0224-02 8-0227-33 8-0227-04 8-0227-05 8-0229-05 8-0229-04 8-0769-01	11-0172 8-0732-01 8-0731-01 8-0731-02 8-0730-33 8-0730-04 8-0730-05 8-0733-05 8-0733-04 8-0769-01
Magellan 8500Q Accessories Cashier Operating Tips - laminated instruction card, English only (sold separately) Mgl 8500 Cashier Training Video (VHS - NTSC Format) Checkstand Fill Kit: Model 8501 & 8502 from NCR 7870/7875 DLC Replacement Glass EAS CheckPoint Antenna Kit EAS Interlock Cable (Requires EAS antenna cable) Kit, Remote Display with 8" post (not included w/scanner) Kit, Remote Display with 22" post (not included w/scanner) Kit, Remote Display, Europe Power Cord, 220V, Europe Power Cord, 220V, Italy/Chile Power Cord, 240V, UK Product Manuals CD (included with scanner) Product Reference Guide (Printed, not included with product) Quick Reference Guide (included with product) Universal Power Supply (requires power cord) US Power Supply Kit (includes supply and standard power cord)	7-0744 R55-0005 11-0038 7-0691 10-3017 8-0278 7-0695 7-0696 7-0687 10-0696 10-0699 10-0697 8-0607-01 R44-2384 R44-2383 7-0685 7-0751	7-0744 R55-0005 11-0209 7-0691 10-4448 8-0769-03 11-0167 11-0168 11-0165 6003-0921 6003-0924 6003-0923 8-0607-01 R44-2384 R44-2383 11-0164 11-0171

PRODUCT	MODEL NUMBER	RoHS MODEL NUMBER
FALCON 4220		
Falcon 4220 - 64MB RAM		
Falcon 4220, Batch, No Scanner *	4220-0000	4220-0000R
Falcon 4220, Batch, Linear Imager *	4220-0002	4220-0002R
Falcon 4220, Batch, Laser *	4220-0001	4220-0001R
Falcon 4220, RF, No Scanner *	4220-1000	4220-1000R
Falcon 4220, RF, Linear Imager *	4220-1002	4220-1002R
Falcon 4220, RF, Laser *	4220-1001	4220-1001R
*Includes: Std Battery, USB Client Cable, AC Power Supply, US Line Cord, Quick Start Guide, CD		
Falcon 4220 - 128MB RAM		
Falcon 4220, RF, Linear Imager *	4220-1102	4220-1102R
Falcon 4220, RF, Laser *	4220-1101	4220-1101R
Falcon 4220 Accessories		
Single Slot Dock (includes USB Client Cable, P/N 6001-2301)	6401-0003	6401-0007
Four Slot Dock (includes power supply, US line cord and mounting brackets)	6401-0004	6401-0012
Ethernet Module for Single Slot Dock	2003-0011	2003-0012
Bluetooth Cover Kit (w/Card)	11-0089	11-0192
Bluetooth Cover Kit (without Card)	11-0092	11-0092
Handle/Pistol Grip	4-3791	4-4475
Standard Battery Pack - 1,800 mAh [1 included with base unit]	4006-0326	4006-0333
High Capacity Battery - 2,700 mAh	4006-0327	4006-0332
Belt Holster (Belt sold separately, P/N 4-3272)	4-3792	4-4476
Belt for Falcon 4220 Holster (for use with P/N 4-3792)	4-3272	4-3272
Car Charging Adapter (Cig Lighter to Terminal)	1406-0967	1406-0976
Screen Protector Kit, 5 Pack	11-0091	11-0091
Spare Stylus - 5 Pack	1406-0968	1406-0968
Product Reference Guide - Printed (electronic included on CD with base unit)	R44-2433	R44-2433
Powered Vehicle Dock Accessories		
Powered Vehicle Dock (Power Supply and Mounting Accessories Sold Separately)	6401-0005	6401-0009
Bare Lead Power Cable, 8 ft. (Included with Dock)	6001-2313	8-0723
DC Filter (Required, Included with Dock)	2701-0002	2701-0004
Auto Delay Shutoff Timer (12V Trucks Only)	2701-0001	2701-0003
DC/DC Converter for 24V to 48VDC Trucks (18-55VDC/10Amp)	4002-0004	TBD
RAM Mount Kit 5.75" Arm, 1.5" Base, 1.5" Base Clamp - 7.5" Total	11-0076	11-0076
RAM Mount, 1.5" Base	2805-0014	2805-0014
RAM Mount, 5.75" Arm (1.5" Sockets) - 7.5" Total	2805-0015	2805-0015
RAM Mount, 1.5" Base Clamo	2805-0016	2805-0016
RAM Mount, 3.5" Arm (1.5" Sockets) - 4.75" Total	2805-0017	2805-0017
RAM Mount, 6" Base Plate	2805-0018	2805-0018
RAM Mount, 5.75" Arm, with (2) 2805-0014 Bundled - 7.5" Total	2805-0022	2805-0022
RAM Mount, 3.5" Arm, with (2) 2805-0014 Bundled - 4.75" Total	2805-0023	2805-0023
Power Supplies (Required for Operation)		
AC Adapter - 110/220V [1 included with base unit]	4004-0779	4004-0804
Power Supply for Powered Vehicle Dock, 110/220 VAC (70w)	4004-0771	N/A
European Line Cord for AC Adapter (IECS)	6001-2307	6001-2319
Falcon 4220 Cables		
USB Client Cable for Terminal [1 included with base unit]	6001-2299	6001-2331
RS232 Cable for Terminal	6001-2300	6001-2317
USB Client Cable for Single Dock [1 included with single dock]	6001-2301	6001-2332
FALCON 4410/20 COLOR WITH OVERMOLD		
WINDOWS MOBILE		
Falcon 4410 - Batch		
Falcon 4410 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, Std Laser	4413-002K1-20000	4413-002K1-20000R
Falcon 4410 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, LR Laser	4413-002K2-20000	4413-002K2-20000R
KEYPAD --> K=0 26 key - K=2 52 key		
Falcon 4410 - 802.11g		
Falcon 4410 w/Overmold, Tether, 64 MB RAM, 64 MB Flash, 802.11g, Std Laser	4413-152K1-20000	4413-152K1-20000R
Falcon 4410 w/Overmold, Tether, 64 MB RAM, 64 MB Flash, 802.11g, LR Laser	4413-152K2-20000	4413-152K2-20000R
KEYPAD --> K=0 26 key - K=2 52 key		
Falcon 4420 - Batch		
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, Std Laser	4423-002K1-20000	4423-002K1-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, LR Laser	4423-002K2-20000	4423-002K2-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, ALR Laser	4423-002K3-20000	4423-002K3-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, Linear Imager	4423-002K4-20000	4423-002K7-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, 2D Imager	4423-002K6-20000	4423-002K8-20000R
KEYPAD --> K=0 26 key - K=2 52 key - K=3 48 key		
Falcon 4420 - 802.11g		
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, Std Laser	4423-152K1-20000	4423-152K1-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, LR Laser	4423-152K2-20000	4423-152K2-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, ALR Laser	4423-152K3-20000	4423-152K3-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, Linear Imager	4423-152K4-20000	4423-152K7-20000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, 2D Imager	4423-152K6-20000	4423-152K8-20000R
KEYPAD --> K=0 26 key - K=1 5250 keypad 52 key - K=2 52 key - K=3 48 key		
WINDOWS CE.NET 5.0		
Falcon 4410 - Batch		
Falcon 4410 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, Std Laser	4413-002K1-10000	4413-002K1-10000R
Falcon 4410 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, LR Laser	4413-002K2-10000	4413-002K2-10000R
KEYPAD --> K=0 26 key - K=2 52 key		
Falcon 4410 - 802.11g		
Falcon 4410 w/Overmold, Tether, 64 MB RAM, 64 MB Flash, 802.11g, Std Laser	4413-152K1-10000	4413-152K1-10000R
Falcon 4410 w/Overmold, Tether, 64 MB RAM, 64 MB Flash, 802.11g, LR Laser	4413-152K2-10000	4413-152K2-10000R
KEYPAD --> K=0 26 key - K=2 52 key		
Falcon 4420 - Batch		
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, Std Laser	4423-002K1-10000	4423-002K1-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, LR Laser	4423-002K2-10000	4423-002K2-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, ALR Laser	4423-002K3-10000	4423-002K3-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, Linear Imager	4423-002K4-10000	4423-002K7-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, Batch, 2D Imager	4423-002K6-10000	4423-002K8-10000R
KEYPAD --> K=0 26 key - K=2 52 key - K=3 48 key		
Falcon 4420 - 802.11g		
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, Std Laser	4423-152K1-10000	4423-152K1-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, LR Laser	4423-152K2-10000	4423-152K2-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, ALR Laser	4423-152K3-10000	4423-152K3-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, Linear Imager	4423-152K4-10000	4423-152K7-10000R
Falcon 4420 w/Overmold, Tether, 64MB RAM, 64 MB Flash, 802.11g, 2D Imager	4423-152K6-10000	4423-152K8-10000R
KEYPAD --> K=0 26 key - K=1 5250 keypad 52 key - K=2 52 key - K=3 48 key - K=5 5250 keypad 48 ke		
Falcon 4400 Series Accessories		
4400 Series Single Slot Dock	7-0856	11-0194
4400 Series Four Slot Charge, Single Com Dock	7-0857	11-0195
Single Slot Dock Accessory Kit (Includes Dock, Power Supply, and IEC/EUR Cord)	11-0093	11-0125
4400 Series Battery	11-0023	11-0023
Coverplate Kit	11-0021	11-0021
Handle Kit	11-0020	11-0020
4400 Series Belt Holster (Belt Sold Separately, P/N 4-3272)	4-3660	4-3660
Softcase with Quick Release Belt Clip (Belt Sold Separately)	4-4135	4-4135
Serial Printer Adapter	11-0072	11-0124
Screen Protector Kit, 5 Pack	11-0091	11-0091
Tethered Stylus Kit	11-0080	11-0153
Stylus Kit, Qty 5	11-0019	11-0019
Quick Release Belt Clip (Included with 4-4135)	4-3327	4-3327
Belt for Falcon 4400 Series Holster / Softcase	4-3272	4-3272
Powered Vehicle Dock Accessories		
Powered Vehicle Dock Kit, Falcon 4400	11-0075	11-0118
Fuse Kit (Required, Included with Dock)	11-0079	11-0159
Bare Lead Power Cable, 8 ft. (Included with Dock)	6001-2313	8-0723
DC Filter (Recommended)	2701-0002	2701-0004
Auto Delay Shutoff Timer (12V Trucks Only)	2701-0001	2701-0003
DC/DC Converter for 24V to 48VDC Trucks (18-55VDC/10Amp)	4002-0004	TBD
RAM Mount Kit 5.75" Arm, 1.5" Base, 1.5" Base Clamp - 7.5" Total	11-0076	11-0076
RAM Mount, 1.5" Base	2805-0014	2805-0014
RAM Mount, 5.75" Arm (1.5" Sockets) - 7.5" Total	2805-0015	2805-0015
RAM Mount, 1.5" Base Clamo	2805-0016	2805-0016
RAM Mount, 3.5" Arm (1.5" Sockets) - 4.75" Total	2805-0017	2805-0017
RAM Mount, 6" Base Plate	2805-0018	2805-0018
RAM Mount, 5.75" Arm, with (2) 2805-0014 Bundled - 7.5" Total	2805-0022	2805-0022
RAM Mount, 3.5" Arm, with (2) 2805-0014 Bundled - 4.75" Total	2805-0023	2805-0023
Power Supplies (Required for Operation)		
Single Slot Dock Power Supply (for PN 7-0856)	4004-0776	4004-0803
4400 Series Four Slot Dock Power Supply (for PN 7-0857)	4004-0787	4004-0805
Power Supply for Powered Vehicle Dock, 110/220 VAC (70w)	4004-0771	N/A
Power Supply (Direct Charge), EMEA with Adaptors	11-0088	11-0088
Power Cord, AC, IEC/EUR	6003-0921	6003-0921
Falcon 4400 Cables		
RS232 Cable, Falcon 4400 Series to PC	8-0653-01	8-0746-01
RS232 Cable, Falcon 4400 Series to Printer (DB9)	8-0653-02	8-0746-02
USB Cable, Falcon 4400 Series to PC, Comm Only	8-0692-01	8-0819-01
RS232 Cable, Falcon 4400 Series Dock to PC	8-0660-01	8-0773-01
USB Cable, Falcon 4400 Series Dock to PC	8-0661-01	8-0661-01

PRODUCT	MODEL NUMBER	RoHS MODEL NUMBER
OMNICOMM		
Standard - 2 utenti	OMN-STD	OMN-STD
Advanced - 5 utenti	OMN-ADV	OMN-ADV
Professional - 10 utenti	OMN-PRF	OMN-PRF
Enterprise - utenti illimitati	OMN-ENT	OMN-ENT
Additional user client - singolo	OMN-ADU1	OMN-ADU1
Additional user client - 5 utenti	OMN-ADU5	OMN-ADU5
SOFTWARE		
PowerNet Twin Client Licenses (v7.0)		
PowerNet Twin Client License, Single (w/user manual and CD)	00-755-01	00-755-01
PowerNet Twin Client License & Formatter, Single (w/user manual and CD)	00-755-02	00-755-02
PowerNet Twin Client License & AirLoader, Single (w/user manual and CD)	00-755-03	00-755-03
PowerNet Twin Client License, Formatter, & Airloader, Single (w/user manual and CD)	00-755-04	00-755-04
PowerNet Twin Client License, Single (no manual or CD)	00-755-11	00-755-11
PowerNet Twin Client License & Formatter, Single (no manual or CD)	00-755-12	00-755-12
PowerNet Twin Client License & AirLoader, Single (no manual or CD)	00-755-13	00-755-13
PowerNet Twin Client License, Formatter, & AirLoader, Single (no manual or CD)	00-755-14	00-755-14
PowerNet v7.0 Upgrade Licenses		
PowerNet Twin Client License, Single Upgrade (w/user manual and CD)	00-755-41	00-755-41
PowerNet Twin Client License & Formatter, Single Upgrade (w/user manual and CD)	00-755-42	00-755-42
PowerNet Twin Client License & AirLoader, Single Upgrade (w/user manual and CD)	00-755-43	00-755-43
PowerNet Twin Client License, Formatter, & Airloader, Single Upgrade (w/user manual and CD)	00-755-44	00-755-44
PowerNet Twin Client License, Single Upgrade (no user manual and CD)	00-755-51	00-755-51
PowerNet Twin Client License & Formatter, Single Upgrade (no user manual and CD)	00-755-52	00-755-52
PowerNet Twin Client License & AirLoader, Single Upgrade (no user manual and CD)	00-755-53	00-755-53
PowerNet Twin Client License, Formatter, & Airloader, Single Upgrade (no user manual and CD)	00-755-54	00-755-54
PowerNet Pre-Loading Services (Non refundable)		
VT100 Emulation Loaded on Falcon Terminal	00-744-40	00-744-40
VT220 Emulation Loaded on Falcon Terminal	00-744-41	00-744-41
HP700/92 Emulation Loaded on Falcon Terminal	00-744-42	00-744-42
IBM 3270 Emulation Loaded on Falcon Terminal	00-744-43	00-744-43
IBM 5250 Emulation Loaded on Falcon Terminal	00-744-44	00-744-44
Wavelink Studio EDGE		
Studio EDGE Client - 1 User	110-LI-STED50	110-LI-STED50
Studio EDGE Client - 1 User Maintenance	110-MA-STED50	110-MA-STED50
Wavelink Studio COM (formerly Studio v3.6)		
Studio COM Server (includes 1 client license)	110-LI-STCS30	110-LI-STCS30
Studio COM Server (includes 1 client license) - Maintenance	110-MA-STCS30	110-MA-STCS30
Studio COM Client - 1 Additional User	110-LI-STCU30	110-LI-STCU30
Studio COM Client - 1 Additional User Maintenance	110-MA-STCU30	110-MA-STCU30
Wavelink Avalanche		
Avalanche (Includes 25 Device Management Licenses)	310-LI-AVCN30	310-LI-AVCN30
Avalanche - Maintenance (Supports 25 Devices)	310-MA-AVCN30	310-MA-AVCN30
Wavelink Avalanche Additional Device Management Licenses		
Avalanche 1 Mobile Device Mgt. License	310-LI-AVH1AD	310-LI-AVH1AD
Avalanche 1 Mobile Device Mgt. License - Maintenance	310-MA-AVH1AD	310-MA-AVH1AD
Wavelink Avalanche Upgrades		
Avalanche Upgrade (Includes 25 Device Management Licenses)	310-LI-AVCNUP	310-LI-AVCNUP
Avalanche Mobile Device Mgt. License Upgrade	310-LI-AVH1UP	310-LI-AVH1UP
Wavelink Mobile Manager Enterprise		
Mobile Manager Enterprise (Includes 25 AP Licenses and 25 Device Management Licenses)	210-LI-MECN10	210-LI-MECN10
Mobile Manager Enterprise - Maintenance	210-MA-MECN10	210-MA-MECN10
Mobile Manager Enterprise 1 AP License	210-LI-ME1A00	210-LI-ME1A00
Mobile Manager Enterprise 1 AP License - Maintenance	210-MA-ME1A00	210-MA-ME1A00
Wavelink Device Management Licenses for Mobile Manager Enterprise		
Mobile Device Mgt. License 1 user	310-LI-AVMEAD	310-LI-AVMEAD
Mobile Device Mgt. License 1 user - Maintenance	310-MA-AVMEAD	310-MA-AVMEAD
Wavelink Mobile Manager		
Mobile Manager (Includes 25 AP Licenses)	210-LI-MMCN50	210-LI-MMCN50
Mobile Manager - Maintenance (Supports 25 APs)	210-MA-MMCN50	210-MA-MMCN50
Mobile Manager 1 AP License	210-LI-MM1A00	210-LI-MM1A00
Mobile Manager 1 AP License - Maintenance	210-MA-MM1A00	210-MA-MM1A00
Mobile Manager Upgrade (Includes 25 AP Licenses)	210-LI-MMCNUP	210-LI-MMCNUP
Mobile Manager AP License Upgrade	210-LI-MM1AUP	210-LI-MM1AUP
Wavelink Client Side Emulators		
Wavelink TN Client for the PSC 325/335/345 4-in-1 (VT100/220, HP900/72/ 5250/3270) [First Year Maintenance Included]	120-LI-PSC340	120-LI-PSC340
Wavelink TN Client for the PSC 325/335/345 4-in-1 Maintenance (Annual)	120-MA-PSC340	120-MA-PSC340
Wavelink TN Client for the PSC 4400 Series 4-in-1 (VT100/220, HP900/72/ 5250/3270) [First Year Maintenance Included]	120-LI-PSC444	120-LI-PSC444
Wavelink TN Client for the PSC 4400 Series 4-in-1 Maintenance (Annual)	120-MA-PSC444	120-MA-PSC444
Wavelink TN Client for the PSC 4220 4-in-1 (VT100/220, HP900/72/ 5250/3270) [First Year Maintenance Included]	120-LI-PSC424	120-LI-PSC424
Wavelink TN Client for the PSC 4220 4-in-1 Maintenance (Annual)	120-MA-PSC424	120-MA-PSC424
Wavelink TN Client for the PSC 4620 4-in-1 (VT100/220, HP900/72/ 5250/3270) [First Year Maintenance Included]	120-LI-PSC464	120-LI-PSC464
Wavelink TN Client for the PSC 4620 4-in-1 Maintenance (Annual)	120-MA-PSC464	120-MA-PSC464
Java Virtual Machine		
JEM-CE JVM License, Single User	JVM-100-01	JVM-100-01
Funk Odyssey Client Software		
Odyssey Client (Falcon 4220 Only)	ODY-V100	ODY-V100
Universal Program Generator (UPG)		
Universal Program Generator (UPG), Full Development System	00-736-00	00-736-00
UPG Demo (download for free from www.pscnet.com)	00-736-30	00-736-30
UPG Upgrade to Current Version	00-736-40	00-736-40
UPG User Manual	R44-2260	R44-2260
PSC Program Generator (PPG)		
PPG Upgrade to Current Version	00-730-40	00-730-40
PSC Program Generator (PPG) Manual	00-655-01	00-655-01

PRODUCT	MODEL NUMBER	RoHS MODEL NUMBER
EMEA ONLY PRODUCTS		
Master B/BB Master B+ standard (multi-ports) Master BB+ standard (mono port, version miniature)	9100000 9000000	9100000-R 9000000-R
Master B/BB Accessories Driver RS232, 2 inputs, 1 output Power Supply, 5V 500mA 220V, Master B+ Power Supply, 5V 500mA 220V, Master BB+ Power Supply, 5V 1A, 220V GS B+ Power Supply, 5V 1A, 220V GS BB+ Display (2 lines x 16 characters) Programming Guide, Master B/BB, French Programming Guide, Master B/BB, English	FATRIRS-PF AH50BST-PF AH5BBST AD50BGS-PF AD5BBGS FSDIS21-PF HNMANFR HNMANUK	FATRIRS-PF-R use AD50BGS-PF-R AH5BBST-R AD50BGS-PF-R AD5BBGS-R FSDIS21-PF-R HNMANFR-R HNMANUK-R
Wedge Cables 13476 WEDGE CABLE W/O MANUAL CABLE EXT 10M WEDGE FOR MASTER CABLE,RS232,MASTER/PCAT 2M CABLE, STI-WEDGE TO IBM3153 CABLE,STI-WEDGE TO IDEA I177P CBL,WEDGE,TERMINAL-RS INPUT ACTIVATED CABLE WYSE (MASTER) IPSPS Wedge Cable IXCABLE WEDGE CABLE - H7000 HP WEDGE CABLE - HOB48 HOB WEDGE CABLE - SUN02 SUN ed. C WEDGE CABLE AMCSE WEDGE CABLE D2420 WEDGE CABLE I3180 USB, V1.5 USB Connector	CW13476 WE104-PF KFMASAT CW13153 CW1177P CWTERW2 CWY162 CWIPSPS CWIXTAT CWH7000-PF CWHOB48-PF CWSUN02 CWAMCSE CWD2420 CW13180 CWUSB15 CWUSB01.5	CW13476-R WE104-PF-R KFMASAT-R CW13153-R CW1177P-R CWTERW2-R CWY162-R CWIPSPS-R CWIXTAT-R CWH7000-PF-R-D CWHOB48-PF-R CWSUN02-R CWAMCSE-R CWD2420-R CW13180-R CWUSB15-R CWUSB01.5-R
SmartNet Cables SMARTNET CABLE - PC NET (2M) RS232 SMARTNET CABLE - COMNET 2M/RS485 SMARTNET IMPEDANCE KIT (2PCS) SMARTNET CABLE - SM 485 SMARTY	CSPCNET FRCN2MT FRIMPKI FRSM485	CSPCNET-R FRCN2MT-R FRIMPKI-R FRSM485-R
Notebook Cables NOTEBOOK CABLE - EXT KEYBOARD, TP350 NOTEBOOK CABLE - IT351 THINKPAD	CNIT350 CNIT351-PF	CNIT350-R CNIT351-PF-R
RS232 Cables CABLE RS-232 CROSSED 25F-25F 2M	KFCC2FF	KFCC2FF-R
PRICE VERIFIERS MODELS & ACCESSORIES		
Genio Standard Color (white) / RS232 Genio Standard Color (white) / Ethernet Genio Standard Color (white) Radio 802.11b Stand for Genio, standard color (yellow) Marco Polo RS232 Marco Polo Ethernet Marco Polo Radio 802,11b Aquarelle CRM Smart kiosk (full options) Options & Extensions Eldat I/R interface for Marco Polo or Genio Language for Marco Polo & Genio - GREEK Links TCP1590 Controller Ethernet Access Point	GENIO GENIO-ETH GENIO 802.11b STAND-GENIO MARCO POLO MARCO POLO-ETH MARCO POLO 802.11b AQUARELLE GEM-CRM - sk -IR -GRE TCP 1590 ETH- ACCESS POINT	GENIO GENIO-ETH GENIO 802.11b STAND-GENIO MARCO POLO MARCO POLO-ETH MARCO POLO 802.11b AQUARELLE GEM-CRM - sk -IR -GRE TCP 1590 ETH- ACCESS POINT